

## DONNEES TECHNIQUES

Length [mm]	<b>595</b>
Number of splines (wheels side)	<b>23</b>
Number of Teeth, ABS ring	<b>30</b>
	<b>for vehicles with ABS</b>
ABS Ring Ø [mm]	<b>87</b>
ABS ring type	<b>R</b>
(wheels side) CV Joint Ø [mm]	<b>98</b>
(gearbox side) rollers Ø [mm]	<b>37</b>

## PHOTOS



## DOCUMENTS

- BT-100** Conseils de montage des cardans
- BT-104** Soufflets et Triaxes FIAT
- BT-105** Soufflets et Triaxes SEAT
- BT-131** Refus des carcasses transmissions

## APPLICATIONS

### RENAULT

SAFRANE (96-00) (B54_) - 2.2 dT (B54G)	113 ch	07.1996 > 12.2000
--	--------	-------------------

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.