

DONNEES TECHNIQUES

Length [mm]	650
Number of splines (wheels side)	20
	for vehicles without ABS
(wheels side) CV Joint Ø [mm]	86
Number of splines (gearbox side)	23
(gearbox side) CV Joint Ø [mm]	110
	Exists R12 Argentina, 630mm long 456TBIS

PHOTOS



DOCUMENTS

- BT-100** Conseils de montage des cardans
- BT-104** Soufflets et Triaxes FIAT
- BT-105** Soufflets et Triaxes SEAT
- BT-131** Refus des carcasses transmissions

APPLICATIONS

RENAULT		
12 - 1.3 (1170)	50 ch	07.1975 > 04.1980
	54 ch	10.1969 > 08.1980
12 - 1.3 TS (1177, 1337)	60 ch	08.1972 > 08.1980
12 - 1.4	67 ch	08.1976 > 05.1979
12 - 1.6 Gordini (1173)	113 ch	08.1970 > 12.1974
12 Break (117_) - 1.3 (1170)	50 ch	07.1975 > 04.1980
	54 ch	10.1970 > 08.1980
12 Break (117_) - 1.3 (1177)	60 ch	08.1973 > 08.1980
12 Société - 1.3	50 ch	07.1975 > 04.1980
15 (130_) - 1.3 (1300)	60 ch	03.1972 > 10.1980
15 (130_) - 1.6 (1302)	90 ch	03.1972 > 10.1980
17 - 1.6	90 ch	03.1972 > 10.1980
17 - 1.6 Gordini	108 ch	03.1974 > 10.1980

⚠ Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.