

DONNEES TECHNIQUES

Length [mm]	650
Number of splines (wheels side)	21
	for vehicles without ABS
(wheels side) shoulder Ø [mm]	50
(wheels side) CV Joint Ø [mm]	86
(gearbox side) rollers Ø [mm]	30

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

RENAULT		
21 (B48_) - 1.7 (B48E)	90 ch	09.1989 > 06.1994
21 (B48_) - 1.7 (B48F)	73 ch	09.1989 > 10.1992
21 (B48_) - 1.9 D (B48H, B48I)	64 ch	09.1989 > 10.1993
21 (B48_) - 1.4 (B48D)	69 ch	09.1989 > 05.1993
21 3 volumes (L48_) - 1.4 (L48D)	69 ch	06.1988 > 10.1993
21 3 volumes (L48_) - 1.7 (L481)	75 ch	03.1986 > 12.1987
21 3 volumes (L48_) - 1.7 (L482)	88 ch	03.1986 > 03.1993
21 3 volumes (L48_) - 1.7 (L48E)	90 ch	09.1989 > 02.1994
	94 ch	03.1986 > 02.1994
21 3 volumes (L48_) - 1.7 (L48M, L48F)	73 ch	07.1986 > 02.1994
21 3 volumes (L48_) - 1.7 (L48N)	87 ch	06.1987 > 04.1989
21 3 volumes (L48_) - 1.9 D (L48H, L48I)	64 ch	08.1989 > 10.1993
21 Break (K48_) - 1.7 (K481, S481)	75 ch	06.1986 > 03.1993
21 Break (K48_) - 1.7 (K482, S482)	88 ch	10.1986 > 12.1988
21 Break (K48_) - 1.7 (K48E)	90 ch	10.1989 > 12.1993
	94 ch	06.1986 > 12.1989
21 Break (K48_) - 1.7 (K48F) KAT	73 ch	05.1988 > 06.1993
21 Break (K48_) - 1.7 (K48M)	73 ch	06.1986 > 12.1989

RENAULT		
21 Break (K48_) - 1.7 (K48N)	87 ch	06.1987 > 04.1989
21 Break (K48_) - 1.9 D	64 ch	03.1986 > 08.1994
21 Nevada Société (S48_) - 1.7	88 ch	06.1986 > 04.1995
21 Nevada Société (S48_) - 1.9 D	64 ch	06.1986 > 08.1994

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.