

DONNEES TECHNIQUES

| | |
|---------------------------------|------------------------------|
| Uncompressed length [mm] | 627 |
| Number of splines (wheels side) | 21 |
| Number of Teeth, ABS ring | 38 |
| | for vehicles with ABS |
| ABS Ring Ø [mm] | 85 |
| ABS ring type | R |
| (wheels side) CV Joint Ø [mm] | 86 |
| (gearbox side) rollers Ø [mm] | 30 |

PHOTOS



DOCUMENTS

| | |
|---------------|--|
| BT-100 | Conseils de montage des cardans |
| BT-104 | Soufflets et Triaxes FIAT |
| BT-105 | Soufflets et Triaxes SEAT |
| BT-131 | Refus des carcasses transmissions |

APPLICATIONS

| RENAULT | | |
|--|-------|-------------------|
| TWINGO (93-06) (C06_) - 1.2 (C063, C064) | 55 ch | 03.1993 > 10.1996 |
| TWINGO (93-06) (C06_) - 1.2 (C066, C068) | 58 ch | 05.1996 > |
| TWINGO (93-06) (C06_) - 1.2 (C067) | 54 ch | 05.1996 > |
| TWINGO (93-06) (C06_) - 1.2 16V (C060) | 60 ch | 08.2004 > |
| TWINGO (93-06) (C06_) - 1.2 16V (C06C, C06D, C06K) | 75 ch | 01.2001 > |
| TWINGO Société (S06_) - 1.2 (S063, S064) | 55 ch | 03.1993 > 05.1996 |
| TWINGO Société (S06_) - 1.2 (S066, S068) | 58 ch | 05.1996 > |

⚠ Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.