

## DONNEES TECHNIQUES

Length [mm]	<b>450</b>
Number of splines (wheels side)	<b>25</b>
Number of Teeth, ABS ring	<b>44</b>
	<b>for vehicles with ABS</b>
Shape of the joint (gearbox side)	<b>Star-form</b>
(wheels side) shoulder Ø [mm]	<b>52</b>
ABS ring type	<b>R</b>
(wheels side) CV Joint Ø [mm]	<b>90</b>
(gearbox side) CV Joint Ø [mm]	<b>72</b>
Diam. ext. plate (A) [mm]	<b>100</b>

## PHOTOS




## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>FIAT</b>		
BRAVA (182) - 1.9 TD 75 S (182.BF)	75 ch	03.1996 > 05.1998
BRAVA (182) - 1.9 TD 100 S (182.BF)	100 ch	03.1996 > 05.1998
BRAVO (95-01) (182) - 1.9 TD 75 S (182.AF)	75 ch	03.1996 > 05.1998
BRAVO (95-01) (182) - 1.9 TD 100 S (182.AF)	100 ch	03.1996 > 05.1998

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.