

## DONNEES TECHNIQUES

Length [mm]	<b>589</b>
Number of splines (wheels side)	<b>25</b>
	<b>for vehicles without ABS</b>
(wheels side) CV Joint Ø [mm]	<b>72</b>
Number of splines (gearbox side)	<b>23</b>
(gearbox side) CV Joint Ø [mm]	<b>78</b>
(gearbox side) shoulder Ø [mm]	<b>40</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>FORD</b>		
KA (96-08) (RB_) - 1.0 i	52 ch	07.1997 > 09.1999
	65 ch	09.1999 >
KA (96-08) (RB_) - 1.3 i	49 ch	06.1998 >
	50 ch	09.1996 > 10.2002
	60 ch	09.1996 >
	70 ch	08.2002 >

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.