

DONNEES TECHNIQUES

Length [mm]	795
Number of splines (wheels side)	28
Number of Teeth, ABS ring	48
	for vehicles with ABS
(wheels side) shoulder Ø [mm]	57
ABS ring type	R
(wheels side) CV Joint Ø [mm]	90
Number of splines (gearbox side)	26
(gearbox side) CV Joint Ø [mm]	88

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

FORD		
TRANSIT (00-06) Bus (FB/C/D/S/Z_ _) - 2.0 DI (F_E_, F_F_, F_G_)	75 ch	08.2000 >
	86 ch	08.2000 >
	100 ch	08.2000 >
TRANSIT (00-06) Camionnette (FA_ _) - 2.0 DI (FAE_, FAF_, FAG_)	75 ch	08.2000 >
	86 ch	08.2000 >
	100 ch	08.2000 >
TRANSIT (00-06) Camionnette (FA_ _) - 2.0 TDCi	125 ch	08.2002 >
TRANSIT (00-06) Plateau (FM/N_ _) - 2.0 DI (F_E_, F_F_)	75 ch	08.2000 >
	86 ch	08.2000 >
	100 ch	08.2000 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.