

## DONNEES TECHNIQUES

Compressed length [mm]	<b>630</b>
Number of splines (wheels side)	<b>25</b>
<b>for vehicles without ABS</b>	
(wheels side) shoulder Ø [mm]	<b>53</b>
(wheels side) CV Joint Ø [mm]	<b>82</b>
Number of splines (gearbox side)	<b>26</b>
(gearbox side) CV Joint Ø [mm]	<b>80</b>
(gearbox side) shoulder Ø [mm]	<b>40</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>FORD</b>		
TOURNEO CONNECT (03-13) - 1.8 16V	116 ch	06.2002 >
TOURNEO CONNECT (03-13) - 1.8 Di	75 ch	06.2002 >
TOURNEO CONNECT (03-13) - 1.8 TDCi	110 ch	08.2006 >
TOURNEO CONNECT (03-13) - 1.8 Turbo Di	90 ch	06.2002 >
TRANSIT CONNECT (03-13) (P65/70/80_) - 1.8 16V	116 ch	06.2002 >
TRANSIT CONNECT (03-13) (P65/70/80_) - 1.8 Di	75 ch	06.2002 >
TRANSIT CONNECT (03-13) (P65/70/80_) - 1.8 TDCi	90 ch	06.2002 >

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.