

DONNEES TECHNIQUES

Length [mm]	735
Number of splines (wheels side)	30
	for vehicles without ABS
(wheels side) CV Joint Ø [mm]	100
Number of splines (gearbox side)	30
(gearbox side) CV Joint Ø [mm]	90
	Exists version with 20x150 thread, ask us.

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

MERCEDES-BENZ		
100 Bus (631) - D	56 ch	12.1990 > 12.1994
100 Bus (631) - D (631.333, 631.343, 631.334, 631.344)	72 ch	02.1988 > 05.1992
	75 ch	12.1990 > 02.1996
100 Camionnette (631) - D (631.332, 631.342)	72 ch	02.1988 > 05.1992
	75 ch	12.1990 > 02.1996
100 plateau (631) - D (631.340)	72 ch	02.1988 > 05.1992
	75 ch	12.1990 > 02.1996

⚠ Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.