

DONNEES TECHNIQUES

Length [mm]	510
Number of splines (wheels side)	27
Number of Teeth, ABS ring	48
	for vehicles with ABS
ABS Ring Ø [mm]	110
ABS ring type	W
(wheels side) CV Joint Ø [mm]	98
(gearbox side) CV Joint Ø [mm]	120

PHOTOS




DOCUMENTS

- BT-100** Conseils de montage des cardans
- BT-104** Soufflets et Triaxes FIAT
- BT-105** Soufflets et Triaxes SEAT
- BT-131** Refus des carcasses transmissions

APPLICATIONS

MERCEDES-BENZ		
CLASSE V (97-03) (638/2) - V 200 CDI (638.294)	102 ch	03.1999 > 07.2003
CLASSE V (97-03) (638/2) - V 220 CDI (638.294)	122 ch	03.1999 > 07.2003
VIANO (W639) - 2.2 CDI	109 ch	09.2003 >
	150 ch	09.2003 >
VIANO (W639) - 3.2	190 ch	09.2003 >
	218 ch	09.2003 >
VIANO (W639) - 3.7	231 ch	06.2004 >
VITO (96-03) (W638) Bus - 108 CDI 2.2 (638.194)	82 ch	03.1999 > 07.2003
VITO (96-03) (W638) Bus - 110 CDI 2.2 (638.194)	102 ch	03.1999 > 07.2003
VITO (96-03) (W638) Bus - 112 CDI 2.2 (638.194)	122 ch	03.1999 > 07.2003
VITO (96-03) (W638) Camionnette - 108 CDI 2.2 (638.094)	82 ch	03.1999 > 07.2003
VITO (96-03) (W638) Camionnette - 110 CDI 2.2 (638.094)	102 ch	03.1999 > 07.2003
VITO (96-03) (W638) Camionnette - 112 CDI 2.2 (638.094)	122 ch	03.1999 > 07.2003
VITO (2003-) (W639) Bus - 109 CDI 2.2	88 ch	09.2003 >
	95 ch	09.2006 >
VITO (2003-) (W639) Bus - 111 CDI 2.2	109 ch	09.2003 >

MERCEDES-BENZ		
VITO (2003-) (W639) Bus - 115 CDI 2.2	150 ch	09.2003 >
VITO (2003-) (W639) Bus - 119	190 ch	09.2003 >
VITO (2003-) (W639) Bus - 122	218 ch	09.2003 >
VITO (2003-) (W639) Bus - 123	231 ch	06.2004 >
VITO (2003-) (W639) Camionnette - 109 CDI 2.2	88 ch	09.2003 >
VITO (2003-) (W639) Camionnette - 111 CDI 2.2	109 ch	09.2003 >
VITO (2003-) (W639) Camionnette - 119 3.2	190 ch	09.2003 >
VITO (2003-) (W639) Camionnette - 122 3.2	218 ch	09.2003 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.