

## DONNEES TECHNIQUES

Length [mm]	<b>635</b>
Number of splines (wheels side)	<b>25</b>
Number of Teeth, ABS ring	<b>48</b>
	<b>for vehicles with ABS</b>
Ø mounting holes [mm]	<b>10</b>
ABS ring type	<b>R or W</b>
Number of mounting bores	<b>6</b>
(wheels side) CV Joint Ø [mm]	<b>96</b>
(gearbox side) CV Joint Ø [mm]	<b>100</b>

## PHOTOS



## DOCUMENTS


<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

### MERCEDES-BENZ

CLASSE C (93-00) (W202) - C180 1.8 (202.018)	121 ch	11.1994 > 05.2000
	122 ch	03.1993 > 05.2000
CLASSE C (93-00) (W202) - C200 2.0 (202.020)	136 ch	01.1994 > 05.2000
CLASSE C (93-00) (W202) - C200 2.0 D (202.120)	75 ch	03.1993 > 05.2000
CLASSE C (93-00) (W202) - C200 2.0 D (202.122)	88 ch	10.1996 > 05.2000
CLASSE C (93-00) (W202) - C200 2.0 Kompressor (202.025)	180 ch	10.1995 > 05.2000
	192 ch	11.1996 > 05.2000
CLASSE C (93-00) (W202) - C200 2.2 CDI (202.134)	102 ch	03.1998 > 05.2000
CLASSE C (93-00) (W202) - C220 2.2 (202.022)	150 ch	03.1993 > 05.2000
CLASSE C (93-00) (W202) - C220 2.2 CDI (202.133)	125 ch	09.1997 > 05.2000
CLASSE C (93-00) (W202) - C220 2.2 D	75 ch	07.1996 > 05.2000
CLASSE C (93-00) (W202) - C220 2.2 D (202.121)	95 ch	08.1993 > 05.2000
CLASSE C (93-00) (W202) - C230 2.3 (202.023)	150 ch	06.1996 > 06.1997
CLASSE C (93-00) (W202) - C230 2.3 Kompressor (202.024)	193 ch	10.1995 > 05.2000
CLASSE C (96-01) Break (S202) - C180 1.8 T (202.078)	122 ch	06.1996 > 09.2000

<b>MERCEDES-BENZ</b>		
CLASSE C (96-01) Break (S202) - C180 2.0 T (202.081)	129 ch	09.2000 > 03.2001
CLASSE C (96-01) Break (S202) - C200 2.0 T (202.080)	136 ch	06.1996 > 03.2001
CLASSE C (96-01) Break (S202) - C200 2.0 T D (202.180)	88 ch	10.1996 > 03.2001
CLASSE C (96-01) Break (S202) - C200 2.0 T Kompressor (202.082)	192 ch	11.1996 > 03.2001
CLASSE C (96-01) Break (S202) - C200 2.0 T Kompressor (202.087)	163 ch	09.2000 > 03.2001
CLASSE C (96-01) Break (S202) - C220 2.2 T D	75 ch	06.1996 > 03.2001
CLASSE C (96-01) Break (S202) - C220 2.2 T D (202.182)	95 ch	06.1996 > 09.1998
CLASSE C (96-01) Break (S202) - C230 2.3 T (202.083)	150 ch	06.1996 > 06.1998
CLASSE C (96-01) Break (S202) - C230 2.3 T Kompressor (202.085)	193 ch	06.1997 > 09.2000
CLK (96-03) (C208) - 200 (208.335)	136 ch	06.1997 > 06.2002
CLK (96-03) (C208) - 200 Kompressor (208.344)	163 ch	06.2000 > 06.2002
CLK (96-03) (C208) - 200 Kompressor (208.345)	192 ch	06.1997 > 06.2000
CLK (96-03) Cabriolet (A208) - 200 (208.435)	136 ch	03.1998 > 03.2002
CLK (96-03) Cabriolet (A208) - 200 Kompressor (208.444)	163 ch	06.2000 > 03.2002

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.