

DONNEES TECHNIQUES

Length [mm]	810
Number of splines (wheels side)	25
Number of Teeth, ABS ring	43
	for vehicles with ABS
ABS Ring Ø [mm]	77
ABS ring type	R
(wheels side) CV Joint Ø [mm]	86
Number of splines (gearbox side)	23
(gearbox side) CV Joint Ø [mm]	86
	Exists Ø82mm version 81901AT

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

VOLVO		
S40 (95-04) (VS) - 1.6	105 ch	09.1995 > 08.1999
	109 ch	03.1999 > 12.2003
S40 (95-04) (VS) - 1.8	115 ch	07.1995 > 08.1999
	122 ch	03.1999 > 12.2003
S40 (95-04) (VS) - 1.8 i	122 ch	06.2001 > 12.2003
	125 ch	03.1998 > 12.2003
S40 (95-04) (VS) - 1.9 DI	95 ch	03.1999 > 07.2000
S40 (95-04) (VS) - 1.9 T4	200 ch	05.1997 > 07.2000
S40 (95-04) (VS) - 1.9 TD	90 ch	07.1995 > 08.1999
S40 (95-04) (VS) - 2.0	136 ch	07.1995 > 12.2003
	140 ch	07.1995 > 08.1999
S40 (95-04) (VS) - 2.0 T	160 ch	10.1997 > 07.2000
	163 ch	06.2001 > 12.2003
	165 ch	07.2000 > 06.2001
S40 (95-04) (VS) - 2.0 T4	200 ch	07.2000 > 12.2003
V40 (95-04) Break (VW) - 1.6	105 ch	12.1995 > 08.1999
	109 ch	03.1999 > 06.2004
V40 (95-04) Break (VW) - 1.8	115 ch	07.1995 > 08.1999
	122 ch	03.1999 > 06.2004
V40 (95-04) Break (VW) - 1.8 i	122 ch	06.2001 > 06.2004
	125 ch	03.1998 > 06.2004
V40 (95-04) Break (VW) - 1.9 DI	95 ch	03.1999 > 07.2000
V40 (95-04) Break (VW) - 1.9 T4	200 ch	05.1997 > 07.2000
V40 (95-04) Break (VW) - 1.9 TD	90 ch	07.1995 > 08.1999
V40 (95-04) Break (VW) - 2.0	136 ch	07.1995 > 06.2004
	140 ch	07.1995 > 08.1999
V40 (95-04) Break (VW) - 2.0 T	160 ch	10.1997 > 07.2000
	163 ch	06.2001 > 06.2004
	165 ch	07.2000 > 06.2001
V40 (95-04) Break (VW) - 2.0 T4	200 ch	07.2000 > 06.2004

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.