

DONNEES TECHNIQUES

Length [mm]	1035
Number of splines (wheels side)	26
Number of Teeth, ABS ring	48
	for vehicles with ABS
ABS ring type	R
(wheels side) CV Joint Ø [mm]	98
Number of splines (gearbox side)	26
(gearbox side) CV Joint Ø [mm]	102

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

VOLVO		
850 (LS) - 2.0	126 ch	08.1994 > 12.1996
	143 ch	06.1991 > 12.1996
850 (LS) - 2.0 Turbo	210 ch	08.1993 > 12.1996
850 (LS) - 2.3 T5	226 ch	08.1993 > 07.1996
850 (LS) - 2.3 T5-R	250 ch	08.1995 > 12.1996
850 (LS) - 2.5	140 ch	06.1991 > 07.1994
	144 ch	08.1994 > 12.1996
	170 ch	08.1991 > 12.1996
850 (LS) - 2.5 TDI	140 ch	08.1995 > 12.1996
850 Break (LW) - 2.0	126 ch	08.1994 > 12.1996
	143 ch	02.1993 > 12.1996
850 Break (LW) - 2.0 Turbo	210 ch	02.1993 > 12.1996
850 Break (LW) - 2.3 T5	226 ch	02.1993 > 12.1996
850 Break (LW) - 2.3 T5-R	250 ch	08.1995 > 12.1996
850 Break (LW) - 2.5	140 ch	08.1992 > 07.1994
	144 ch	08.1994 > 12.1996

VOLVO		
(suite) 850 Break (LW) - 2.5	170 ch	09.1992 > 12.1996
850 Break (LW) - 2.5 TDI	140 ch	08.1995 > 12.1996
C70 (97-06) Cabriolet - 2.0 T	163 ch	03.2000 > 10.2005
	226 ch	03.1998 > 10.2005
C70 (97-06) Cabriolet - 2.3 T-5	239 ch	03.1998 > 10.2005
	245 ch	07.2002 > 10.2005
C70 (97-06) Cabriolet - 2.4 T	200 ch	07.2002 > 10.2005
C70 (97-06) Cabriolet - 2.5 T	193 ch	03.1998 > 10.2005
C70 (97-06) Coupe - 2.0 T	163 ch	03.2000 > 09.2002
	226 ch	03.1997 > 09.2002
C70 (97-06) Coupe - 2.3 T-5	240 ch	03.1997 > 09.2002
C70 (97-06) Coupe - 2.5 T	193 ch	03.1997 > 09.2002
S70 (P80_) - 2.0 Turbo	210 ch	01.1997 > 12.1998
	226 ch	01.1997 > 12.1998
S70 (P80_) - 2.3 T-5	239 ch	01.1997 > 12.1998
S70 (P80_) - 2.3 Turbo	250 ch	01.1997 > 12.1998
S70 (P80_) - 2.4 Turbo	193 ch	01.1997 > 12.1998
S70 (P80_) - 2.5 TDI	140 ch	01.1997 > 12.1998
V70 (97-00) Break (P80_) - 2.0 Turbo	211 ch	01.1997 > 03.2000
	226 ch	01.1997 > 03.2000
V70 (97-00) Break (P80_) - 2.0 Turbo AWD	226 ch	01.1997 > 03.2000
V70 (97-00) Break (P80_) - 2.3 T AWD	250 ch	04.1997 > 03.2000
V70 (97-00) Break (P80_) - 2.3 T-5	239 ch	01.1997 > 03.2000
V70 (97-00) Break (P80_) - 2.3 T-5 AWD	239 ch	01.1997 > 03.2000
V70 (97-00) Break (P80_) - 2.3 Turbo	250 ch	01.1997 > 03.2000
V70 (97-00) Break (P80_) - 2.4 Turbo	193 ch	01.1997 > 03.2000
V70 (97-00) Break (P80_) - 2.5 TDI	140 ch	01.1997 > 05.2000
V70 (97-00) Break (P80_) - 2.5 Turbo AWD	193 ch	01.1997 > 05.2000

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.