

DONNEES TECHNIQUES

Length [mm]	750
Number of splines (wheels side)	22
	for vehicles without ABS
Ø mounting holes [mm]	8
(wheels side) shoulder Ø [mm]	50
Number of mounting bores	6
(wheels side) CV Joint Ø [mm]	81
(gearbox side) CV Joint Ø [mm]	94

PHOTOS



DOCUMENTS


BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

VOLKSWAGEN		
CADDY (79-96) (14) - 1.5	70 ch	08.1982 > 07.1983
CADDY (79-96) (14) - 1.6	75 ch	01.1983 > 07.1992
	75 ch	10.1982 > 10.1983
CADDY (79-96) (14) - 1.6 D	55 ch	08.1982 > 07.1992
CADDY (79-96) (14) - 1.8	95 ch	08.1985 > 07.1992
GOLF (74-83) Cabriolet (155) - 1.6	72 ch	04.1986 > 08.1987
	75 ch	08.1983 > 08.1987
GOLF (74-83) Cabriolet (155) - 1.8	90 ch	08.1983 > 08.1987
	95 ch	08.1983 > 08.1987
	98 ch	08.1989 > 03.1993
	112 ch	08.1982 > 08.1987
SCIROCCO (82-92) (53B) - 1.3	60 ch	08.1980 > 12.1983
SCIROCCO (82-92) (53B) - 1.6	70 ch	08.1983 > 07.1984
	72 ch	04.1986 > 07.1990
	75 ch	01.1983 > 12.1989
	85 ch	08.1980 > 04.1984

VOLKSWAGEN

(suite) SCIROCCO (82-92) (53B) - 1.6	110 ch	08.1980 > 07.1982
SCIROCCO (82-92) (53B) - 1.8	90 ch	08.1983 > 07.1992

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.