

## DONNEES TECHNIQUES

Length [mm]	<b>515</b>
Number of splines (wheels side)	<b>22</b>
	<b>for vehicles without ABS</b>
(wheels side) shoulder Ø [mm]	<b>53</b>
(wheels side) CV Joint Ø [mm]	<b>81</b>
(gearbox side) CV Joint Ø [mm]	<b>90</b>
Number of mounting bores	<b>6</b>
Ø mounting holes [mm]	<b>8</b>

## PHOTOS




## DOCUMENTS

- BT-100**    **Conseils de montage des cardans**
- BT-104**    **Soufflets et Triaxes FIAT**
- BT-105**    **Soufflets et Triaxes SEAT**
- BT-131**    **Refus des carcasses transmissions**

## APPLICATIONS

<b>SEAT</b>		
AROSA (6H) - 1.0	50 ch	05.1997 > 10.2000
AROSA (6H) - 1.4	60 ch	05.1997 > 10.2000
AROSA (6H) - 1.4 16V	100 ch	01.2000 > 06.2004
AROSA (6H) - 1.7 SDI	60 ch	08.1997 > 10.2000

<b>VOLKSWAGEN</b>		
POLO (94-99) (6N1) - 1.7 SDI	57 ch	04.1997 > 10.1999
POLO (94-99) (6N1) - 100 1.4 16V	100 ch	04.1996 > 10.1999
POLO (94-99) (6N1) - 45 1.0	45 ch	10.1994 > 09.1996
POLO (94-99) (6N1) - 50 1.0	50 ch	09.1996 > 10.1999
POLO (94-99) (6N1) - 55 1.3	55 ch	10.1994 > 07.1995
POLO (94-99) (6N1) - 55 1.4	55 ch	08.1995 > 10.1999
POLO (94-99) (6N1) - 60 1.4	60 ch	07.1995 > 10.1999
POLO (94-99) (6N1) - 60 1.7 SDI	60 ch	08.1997 > 10.1999
POLO (94-99) (6N1) - 64 1.9 D	64 ch	10.1994 > 10.1999
POLO (94-99) (6N1) - 64 1.9 SDI	64 ch	07.1996 > 10.1999
POLO (94-99) (6N1) - 75 1.6	75 ch	10.1994 > 10.1999
POLO (94-99) Camionnette (6NF) - 1.0	45 ch	10.1994 > 12.1999
POLO (94-99) Camionnette (6NF) - 1.4	60 ch	05.1998 > 12.1999
POLO (94-99) Camionnette (6NF) - 1.7 SDI	60 ch	08.1997 > 12.1999
POLO (94-99) Camionnette (6NF) - 1.9 D	64 ch	10.1994 > 12.1999
POLO (94-99) Camionnette (6NF) - 1.9 SDI	64 ch	07.1996 > 12.1999

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.