

## DONNEES TECHNIQUES

Length [mm]	<b>608</b>
Number of splines (wheels side)	<b>22</b>
	<b>for vehicles without ABS</b>
Ø mounting holes [mm]	<b>8</b>
Number of mounting bores	<b>6</b>
(wheels side) CV Joint Ø [mm]	<b>81</b>
(gearbox side) CV Joint Ø [mm]	<b>94</b>

## PHOTOS




## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>VOLKSWAGEN</b>		
GOLF (83-92) (19E, 1G1) - 1.8 Syncro	90 ch	02.1986 > 07.1989
	98 ch	08.1988 > 07.1989
GOLF (83-92) (19E, 1G1) - 1.8 i Syncro KAT	90 ch	08.1987 > 07.1989
JETTA (84-92) (A2, 1G2) - 1.8 Syncro	90 ch	08.1987 > 12.1988
	98 ch	08.1988 > 07.1989

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.