

DONNEES TECHNIQUES

Length [mm]	795
Number of splines (wheels side)	22
	for vehicles without ABS
(wheels side) CV Joint Ø [mm]	81
(gearbox side) CV Joint Ø [mm]	94
Number of mounting bores	6
Ø mounting holes [mm]	8

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

VOLKSWAGEN		
GOLF (91-99) (1H1) - 1.4	55 ch	11.1991 > 08.1997
	60 ch	11.1991 > 08.1997
GOLF (91-99) (1H1) - 1.6	75 ch	09.1992 > 08.1997
	101 ch	07.1995 > 08.1997
GOLF (91-99) (1H1) - 1.9 D	65 ch	11.1991 > 08.1997
GOLF (91-99) (1H1) - 1.9 SDI	64 ch	04.1997 > 08.1997
GOLF (91-99) Cabriolet (1E7) - 1.6	101 ch	10.1994 > 05.1998
GOLF (91-99) Break (1H5) - 1.6	75 ch	08.1994 > 12.1997
	101 ch	07.1994 > 04.1999
GOLF (91-99) Break (1H5) - 1.9 D	65 ch	07.1993 > 04.1999
GOLF (91-99) Break (1H5) - 1.9 SDI	64 ch	04.1997 > 04.1999
GOLF (98-02) Cabriolet (1E7) - 1.6	100 ch	06.1998 > 06.2002
PASSAT (88-96) (3A2, 35I) - 1.6	72 ch	02.1988 > 09.1991
	75 ch	02.1988 > 12.1988
PASSAT (88-96) (3A2, 35I) - 1.6 TD	80 ch	08.1988 > 09.1993
PASSAT (88-97) Variant (3A5, 35I) - 1.6	72 ch	04.1988 > 09.1991
	75 ch	04.1988 > 12.1988

VOLKSWAGEN		
PASSAT (88-97) Variant (3A5, 35I) - 1.6 TD	80 ch	08.1988 > 07.1990
VENTO (92-99) (1H2) - 1.4	55 ch	11.1991 > 09.1998
	60 ch	11.1991 > 09.1998
VENTO (92-99) (1H2) - 1.6	75 ch	09.1992 > 09.1998
	101 ch	10.1994 > 09.1998
VENTO (92-99) (1H2) - 1.9 D	65 ch	11.1991 > 09.1998
VENTO (92-99) (1H2) - 1.9 SDI	64 ch	04.1997 > 09.1998

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.