

## DONNEES TECHNIQUES

Length [mm]	<b>785</b>
Number of splines (wheels side)	<b>36</b>
	<b>for vehicles without ABS</b>
Ø mounting holes [mm]	<b>8</b>
Number of mounting bores	<b>6</b>
(wheels side) CV Joint Ø [mm]	<b>90</b>
(gearbox side) CV Joint Ø [mm]	<b>100</b>

## PHOTOS




## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>SEAT</b>		
TOLEDO (91-99) (1L) - 2.0 i 16V	150 ch	11.1993 > 03.1999

<b>VOLKSWAGEN</b>		
CORRADO (53I) - 2.9 VR6	190 ch	08.1991 > 12.1995
GOLF (91-99) (1H1) - 2.0	115 ch	11.1991 > 08.1997
GOLF (91-99) (1H1) - 2.0 GTI 16V	150 ch	08.1992 > 08.1997
GOLF (91-99) (1H1) - 2.8 VR6	174 ch	01.1992 > 08.1997
GOLF (91-99) Break (1H5) - 2.0	115 ch	07.1993 > 04.1999
VENTO (92-99) (1H2) - 2.0	115 ch	11.1991 > 09.1998
VENTO (92-99) (1H2) - 2.8 VR6	174 ch	01.1992 > 09.1998

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.