

DONNEES TECHNIQUES

Length [mm]	820
Number of splines (wheels side)	36
	for vehicles without ABS
(wheels side) CV Joint Ø [mm]	90
(gearbox side) CV Joint Ø [mm]	100
Number of mounting bores	6
Ø mounting holes [mm]	8

PHOTOS



DOCUMENTS

- BT-100** Conseils de montage des cardans
- BT-104** Soufflets et Triaxes FIAT
- BT-105** Soufflets et Triaxes SEAT
- BT-131** Refus des carcasses transmissions

APPLICATIONS


AUDI		
A3 (96-03) (8L1) - 1.8	125 ch	09.1996 >
A3 (96-03) (8L1) - 1.9 TDI	90 ch	09.1996 > 07.2001
	100 ch	10.2000 > 05.2003
	110 ch	08.1997 > 07.2001

SEAT		
LEON (98-06) (1M1) - 1.8 20V	125 ch	11.1999 >
LEON (98-06) (1M1) - 1.9 TDI	90 ch	11.1999 >
	100 ch	10.2005 >
	110 ch	11.1999 >
TOLEDO (99-06) (1M2) - 1.8 20V	125 ch	04.1999 > 05.2006
TOLEDO (99-06) (1M2) - 1.9 TDI	90 ch	04.1999 > 05.2006
	110 ch	04.1999 > 05.2006

SKODA		
OCTAVIA (96-10) (1U2) - 1.8	125 ch	09.1996 >
OCTAVIA (96-10) (1U2) - 1.9 TDI	90 ch	09.1996 >
	110 ch	08.1997 >
OCTAVIA (96-10) (1U2) - 2.0	116 ch	04.1999 >
OCTAVIA (96-10) Combi (1U5) - 1.8 20V	125 ch	07.1998 >
OCTAVIA (96-10) Combi (1U5) - 1.9 TDI	90 ch	07.1998 >
	110 ch	07.1998 >
OCTAVIA (96-10) Combi (1U5) - 1.9 TDI 4x4	90 ch	11.1999 > 09.2000
OCTAVIA (96-10) Combi (1U5) - 2.0	116 ch	04.1999 >
OCTAVIA (96-10) Combi (1U5) - 2.0 4x4	116 ch	05.2001 >

VOLKSWAGEN		
BORA (1J2) - 1.8	125 ch	10.1998 > 05.2005
BORA (1J2) - 1.8 4motion	125 ch	02.1999 > 05.2005
BORA (1J2) - 1.9 TDI	90 ch	10.1998 > 06.2001
	101 ch	09.2000 > 05.2005
	110 ch	10.1998 > 06.2001
BORA (1J2) - 1.9 TDI 4motion	90 ch	02.1999 > 06.2001
	101 ch	09.2000 > 05.2005
BORA (1J2) - 2.0	115 ch	10.1998 > 05.2005
BORA (1J2) - 2.0 4motion	115 ch	04.2000 > 05.2005
BORA Break (1J6) - 1.8 4motion	125 ch	05.1999 > 05.2005
BORA Break (1J6) - 1.9 TDI	90 ch	05.1999 > 06.2001
	101 ch	09.2000 > 05.2005
	110 ch	05.1999 > 06.2001
BORA Break (1J6) - 1.9 TDI 4motion	101 ch	09.2000 > 05.2005
BORA Break (1J6) - 2.0	115 ch	05.1999 > 05.2005
BORA Break (1J6) - 2.0 4motion	115 ch	04.2000 > 05.2005
GOLF (97-05) (1J1) - 1.8	125 ch	08.1997 > 06.2005
GOLF (97-05) (1J1) - 1.8 4motion	125 ch	05.1998 > 06.2005
GOLF (97-05) (1J1) - 1.9 TDI	90 ch	10.1997 > 05.2004
	101 ch	09.2000 > 06.2005
	110 ch	08.1997 > 05.2004
GOLF (97-05) (1J1) - 1.9 TDI 4motion	90 ch	07.1998 > 04.2002
	101 ch	09.2000 > 06.2005
GOLF (97-05) (1J1) - 2.0	115 ch	07.1998 > 06.2005
GOLF (97-05) (1J1) - 2.0 4motion	115 ch	10.2000 > 06.2005
GOLF (98-02) Cabriolet (1E7) - 2.0	115 ch	06.1998 > 06.2002
GOLF (99-05) Break (1J5) - 1.8 4motion	125 ch	05.1999 >
GOLF (99-05) Break (1J5) - 1.9 TDI	90 ch	05.1999 > 05.2006
	101 ch	09.2000 >
	110 ch	05.1999 > 06.2001

VOLKSWAGEN		
GOLF (99-05) Break (1J5) - 1.9 TDI 4motion	90 ch	05.1999 > 04.2002
	101 ch	09.2000 >
GOLF (99-05) Break (1J5) - 2.0	115 ch	05.1999 >
GOLF (99-05) Break (1J5) - 2.0 4motion	115 ch	10.2000 >
NEW BEETLE (97-11) (9C1, 1C1) - 1.6	102 ch	09.2000 >
NEW BEETLE (97-11) (9C1, 1C1) - 1.9 TDI	90 ch	01.1998 > 02.2001
	101 ch	02.2001 >
NEW BEETLE (97-11) (9C1, 1C1) - 2.0	115 ch	01.1998 >
NEW BEETLE Cabriolet (1Y7) - 1.6	102 ch	01.2003 >
NEW BEETLE Cabriolet (1Y7) - 1.9 TDI	100 ch	03.2003 >
NEW BEETLE Cabriolet (1Y7) - 2.0	115 ch	01.2003 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.