

DONNEES TECHNIQUES

Length [mm]	821
Number of splines (wheels side)	36
for vehicles without ABS	
(wheels side) shoulder Ø [mm]	53
(wheels side) CV Joint Ø [mm]	81
(gearbox side) CV Joint Ø [mm]	94
Number of mounting bores	6
Ø mounting holes [mm]	8

PHOTOS




DOCUMENTS

- BT-100** Conseils de montage des cardans
- BT-104** Soufflets et Triaxes FIAT
- BT-105** Soufflets et Triaxes SEAT
- BT-131** Refus des carcasses transmissions

APPLICATIONS

SEAT		
TOLEDO (99-06) (1M2) - 1.4 16V	75 ch	07.1999 > 05.2006
TOLEDO (99-06) (1M2) - 1.6	100 ch	04.1999 > 09.2000
TOLEDO (99-06) (1M2) - 1.9 SDI	68 ch	11.1999 > 06.2004

VOLKSWAGEN		
BORA (1J2) - 1.4 16V	75 ch	03.2000 > 05.2005
BORA (1J2) - 1.6	101 ch	10.1998 > 05.2005
	102 ch	08.2000 > 05.2005
BORA (1J2) - 1.9 SDI	68 ch	10.1998 > 05.2005
BORA Break (1J6) - 1.4 16V	75 ch	09.2001 > 05.2005
BORA Break (1J6) - 1.6	100 ch	05.1999 > 05.2005
	102 ch	08.2000 > 05.2005
GOLF (97-05) (1J1) - 1.4 16V	75 ch	08.1997 > 06.2005
GOLF (97-05) (1J1) - 1.6	100 ch	08.1997 > 02.2000
	102 ch	08.2000 > 06.2005
GOLF (99-05) Break (1J5) - 1.4 16V	75 ch	05.1999 >
GOLF (99-05) Break (1J5) - 1.6	101 ch	05.1999 > 02.2000
	102 ch	08.2000 >
GOLF PLUS (5M1, 521) - 1.4 16V	75 ch	01.2005 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.