

DONNEES TECHNIQUES

Length [mm]	539
Number of splines (wheels side)	22
	for vehicles without ABS
(wheels side) CV Joint Ø [mm]	81
(gearbox side) CV Joint Ø [mm]	94
Number of mounting bores	6
Ø mounting holes [mm]	8

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

VOLKSWAGEN		
CADDY (96-04) Break (9K9B) - 1.6	75 ch	11.1995 > 05.1997
	75 ch	06.1997 > 09.2000
CADDY (96-04) Break (9K9B) - 1.7 SDI	57 ch	07.1996 > 09.2000
CADDY (96-04) Break (9K9B) - 1.9 D	64 ch	11.1995 > 01.2004
CADDY (96-04) Break (9K9B) - 1.9 SDI	64 ch	11.1995 > 01.2004
CADDY (96-04) Camionnette (9K9A) - 1.7 SDI	57 ch	07.1996 > 09.2000
CADDY (96-04) Camionnette (9K9A) - 1.9 D	64 ch	11.1995 > 01.2004
CADDY (96-04) Camionnette (9K9A) - 1.9 SDI	64 ch	11.1995 > 01.2004
CADDY (96-04) Camionnette (9K9A) - 75 1.6	75 ch	11.1995 > 09.2000
	75 ch	11.1995 > 05.1997
CADDY (96-00) Pick-up (9U7) - 1.6	75 ch	06.1996 > 12.2000
CADDY (96-00) Pick-up (9U7) - 1.9 D	64 ch	06.1996 > 12.2000
FLIGHT 3 volumes (6KV2) - 57 1.7 SDI	57 ch	07.1997 > 09.2001
FLIGHT 3 volumes (6KV2) - 64 1.9 D	64 ch	01.1996 > 10.1996
FLIGHT 3 volumes (6KV2) - 64 1.9 SDI	64 ch	12.1995 > 08.1999
FLIGHT 3 volumes (6KV2) - 68 1.9 SDI	68 ch	08.1999 > 09.2001
FLIGHT 3 volumes (6KV2) - 100 1.6	100 ch	12.1995 > 09.2001

VOLKSWAGEN		
POLO (97-02) Variant (6KV5) - 1.6	101 ch	05.1997 > 09.2001
POLO (97-02) Variant (6KV5) - 1.7 SDI	57 ch	08.1997 > 09.2001
POLO (97-02) Variant (6KV5) - 1.9 SDI	64 ch	06.1997 > 09.2001
	68 ch	08.1999 > 09.2001

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.