

## DONNEES TECHNIQUES

Length [mm]	<b>813</b>
Number of splines (wheels side)	<b>36</b>
	<b>for vehicles without ABS</b>
Ø mounting holes [mm]	<b>8</b>
Thread (wheels side)	<b>FEMELLE</b>
(wheels side) shoulder Ø [mm]	<b>59</b>
Number of mounting bores	<b>6</b>
(wheels side) CV Joint Ø [mm]	<b>90</b>
(gearbox side) CV Joint Ø [mm]	<b>100</b>

## PHOTOS




## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>AUDI</b>		
A3 (03-12) (8P1) - 1.6 TDI	90 ch	05.2009 >
	105 ch	05.2009 >
A3 (03-12) (8P1) - 1.9 TDI	105 ch	05.2003 >
A3 (04-12) Sportback (8PA) - 1.6 TDI	90 ch	05.2009 >
	105 ch	05.2009 >
A3 (04-12) Sportback (8PA) - 1.9 TDI	105 ch	09.2004 >
A3 (08-12) Cabriolet (8P7) - 1.6 TDI	105 ch	05.2009 >

<b>SEAT</b>		
ALTEA (5P1) - 1.9 TDI	105 ch	04.2004 >
LEON (05-12) (1P1) - 1.6 TDI	105 ch	02.2010 >
LEON (05-12) (1P1) - 1.9 TDI	105 ch	09.2005 >
LEON (05-12) (1P1) - 2.0 FSI	150 ch	09.2005 >
TOLEDO (04-09) (5P2) - 2.0 FSI	150 ch	10.2004 >
<b>SKODA</b>		
OCTAVIA (04-13) (1Z3) - 1.9 TDI	105 ch	06.2004 >
OCTAVIA (04-13) (1Z3) - 2.0 FSI	150 ch	11.2004 >
<b>VOLKSWAGEN</b>		
CADDY (2004-) Camionnette (2KA, 2KH) - 2.0 SDI	70 ch	03.2004 >
GOLF (03-09) (1K1) - 1.9 TDI	105 ch	10.2003 >
GOLF (08-12) (5K1) - 1.6 TDI	105 ch	02.2009 >
GOLF PLUS (5M1, 521) - 1.9 TDI	90 ch	05.2005 >
	105 ch	01.2005 >
PASSAT (05-10) (3C2) - 1.9 TDI	105 ch	03.2005 >
TOURAN (06-10) (1T1, 1T2) - 1.9 TDI	90 ch	11.2004 >
	100 ch	02.2003 >
	105 ch	08.2003 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.