

## DONNEES TECHNIQUES

Length [mm]	<b>750</b>
Number of splines (wheels side)	<b>22</b>
	<b>for vehicles without ABS</b>
(wheels side) CV Joint Ø [mm]	<b>81</b>
(gearbox side) CV Joint Ø [mm]	<b>94</b>
Number of mounting bores	<b>6</b>
Ø mounting holes [mm]	<b>8</b>

## PHOTOS




## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>SEAT</b>		
AROSA (6H) - 1.0	50 ch	11.2000 > 06.2004
AROSA (6H) - 1.4	60 ch	11.2000 > 06.2004
AROSA (6H) - 1.7 SDI	60 ch	11.2000 > 06.2004
CORDOBA (96-02) 3/5 portes (6K2) - 1.9 SDI	68 ch	06.1999 > 10.2002
CORDOBA (96-02) Vario (6K5) - 1.9 SDI	68 ch	06.1999 >
IBIZA (99-02) (6K2, 6K/GP01) - 1.9 SDI	68 ch	08.1999 > 02.2002
INCA (6K9) - 1.9 SDI	64 ch	08.1999 >

<b>VOLKSWAGEN</b>		
LUPO - 1.0	50 ch	09.1998 > 07.2005
LUPO - 1.4	60 ch	10.2000 > 07.2005
LUPO - 1.4 16V	75 ch	09.1998 > 07.2005
	100 ch	08.1999 > 07.2005
LUPO - 1.6 GTI	125 ch	09.2000 > 07.2005
LUPO - 1.7 SDI	60 ch	09.1998 > 07.2005
POLO (99-02) (6N2) - 1.0	50 ch	10.1999 > 09.2001
POLO (99-02) (6N2) - 1.4	54 ch	10.1999 > 09.2001
	60 ch	10.1999 > 09.2001
POLO (99-02) (6N2) - 1.4 16V	75 ch	10.1999 > 09.2001
	101 ch	10.1999 > 09.2001
POLO (99-02) (6N2) - 1.7 SDI	60 ch	10.1999 > 09.2001
POLO (99-02) (6N2) - 1.9 D	64 ch	10.1999 > 09.2001
POLO (99-02) (6N2) - 1.9 SDI	64 ch	10.1999 > 09.2001

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.