

DONNEES TECHNIQUES

Length [mm]	525
Number of splines (wheels side)	22
	for vehicles without ABS
(wheels side) CV Joint Ø [mm]	81
(gearbox side) CV Joint Ø [mm]	94
Number of mounting bores	6
Ø mounting holes [mm]	8

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

SEAT		
AROSA (6H) - 1.0	50 ch	11.2000 > 06.2004
AROSA (6H) - 1.4	60 ch	11.2000 > 06.2004
AROSA (6H) - 1.7 SDI	60 ch	11.2000 > 06.2004
CORDOBA (96-02) 3/5 portes (6K2) - 1.9 SDI	68 ch	06.1999 > 10.2002
CORDOBA (96-02) Vario (6K5) - 1.9 SDI	68 ch	06.1999 >
IBIZA (99-02) (6K2, 6K/GP01) - 1.9 SDI	68 ch	08.1999 > 02.2002
INCA (6K9) - 1.9 SDI	64 ch	08.1999 >

VOLKSWAGEN		
LUPO - 1.0	50 ch	09.1998 > 07.2005
LUPO - 1.4	60 ch	10.2000 > 07.2005
LUPO - 1.4 16V	75 ch	09.1998 > 07.2005
	100 ch	08.1999 > 07.2005
LUPO - 1.7 SDI	60 ch	09.1998 > 07.2005
POLO (99-02) (6N2) - 1.0	50 ch	10.1999 > 09.2001
POLO (99-02) (6N2) - 1.4	54 ch	10.1999 > 09.2001
	60 ch	10.1999 > 09.2001
POLO (99-02) (6N2) - 1.4 16V	75 ch	10.1999 > 09.2001
	101 ch	10.1999 > 09.2001
POLO (99-02) (6N2) - 1.7 SDI	60 ch	10.1999 > 09.2001
POLO (99-02) (6N2) - 1.9 D	64 ch	10.1999 > 09.2001
POLO (99-02) (6N2) - 1.9 SDI	64 ch	10.1999 > 09.2001

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.