

## DONNEES TECHNIQUES

Length [mm]	<b>500</b>
Number of splines (wheels side)	<b>38</b>
Number of Teeth, ABS ring	<b>45</b>
	<b>for vehicles with ABS</b>
ABS Ring Ø [mm]	<b>81</b>
Shape of the joint (gearbox side)	<b>Star-form</b>
ABS ring type	<b>W</b>
(wheels side) CV Joint Ø [mm]	<b>98</b>
(gearbox side) CV Joint Ø [mm]	<b>90</b>
Diam. ext. plate (A) [mm]	<b>130</b>
Number of mounting bores	<b>6</b>
Ø mounting holes [mm]	<b>10</b>

## PHOTOS




## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>VOLKSWAGEN</b>		
PASSAT (96-00) (3B2) - 2.5 TDI	150 ch	07.1998 > 11.2000
PASSAT (96-00) (3B2) - 2.5 TDI Syncro/4motion	150 ch	12.1998 > 11.2000
PASSAT (96-00) Variant (3B5) - 2.5 TDI	150 ch	07.1998 > 11.2000
PASSAT (96-00) Variant (3B5) - 2.5 TDI Syncro/4motion	150 ch	12.1998 > 11.2000

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.