

DONNEES TECHNIQUES

Compressed length [mm]	860
Number of splines (wheels side)	38
	for vehicles without ABS
(wheels side) shoulder Ø [mm]	63
(wheels side) CV Joint Ø [mm]	100
Number of splines (gearbox side)	26
(gearbox side) CV Joint Ø [mm]	102
	Coupler assembly (gearbox side) : ARCOUP1

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

VOLKSWAGEN

TRANSPORTER (03-15) T5 Bus (7HB, 7HJ) - 1.9 TDI	85 ch	04.2003 >
---	-------	-----------

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.