

## DONNEES TECHNIQUES

Length [mm]	<b>625</b>
Number of splines (wheels side)	<b>26</b>
Number of Teeth, ABS ring	<b>50</b>
	<b>for vehicles with ABS</b>
(wheels side) shoulder Ø [mm]	<b>55</b>
ABS ring type	<b>R</b>
(wheels side) CV Joint Ø [mm]	<b>80</b>
Number of splines (gearbox side)	<b>25</b>
(gearbox side) CV Joint Ø [mm]	<b>85</b>

## PHOTOS




## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>HONDA</b>		
CIVIC (92-95) Coupe (EJ) - 1.5 i LSi (EJ2)	101 ch	01.1994 > 11.1995
CIVIC (92-95) Coupe (EJ) - 1.6 i (EJ6)	105 ch	01.1994 > 11.1995
CIVIC (92-95) Coupe (EJ) - 1.6 i Vtec (EJ1)	125 ch	01.1994 > 03.1996

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.