

DONNEES TECHNIQUES

Length [mm]	615
Number of splines (wheels side)	26
	for vehicles without ABS
(wheels side) shoulder Ø [mm]	55
(wheels side) CV Joint Ø [mm]	83
Number of splines (gearbox side)	27
(gearbox side) CV Joint Ø [mm]	84

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

HONDA		
PRELUDE (87-91) (BA) - 2.0 (BA4)	114 ch	08.1987 > 01.1992
PRELUDE (87-91) (BA) - 2.0 EX (BA4)	109 ch	04.1987 > 01.1992
PRELUDE (87-91) (BA) - 2.0 i EX 16V	137 ch	10.1987 > 12.1987
	150 ch	10.1987 > 12.1990
PRELUDE (87-91) (BA) - 2.0 i EX 16V (BA2)	137 ch	10.1987 > 12.1987
PRELUDE (87-91) (BA) - 2.0 i EX 16V (BA4)	140 ch	10.1987 > 01.1992
PRELUDE (87-91) (BA) - 2.0 i EX 16V (BA4) KAT	137 ch	10.1987 > 01.1992
PRELUDE (82-96) (BB) - 2.0 i 16V (BB3)	133 ch	02.1992 > 09.1996

⚠ Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.