

DONNEES TECHNIQUES

Length [mm]	890
Number of splines (wheels side)	25
	for vehicles without ABS
(wheels side) shoulder Ø [mm]	52
(wheels side) CV Joint Ø [mm]	80
Number of splines (gearbox side)	24
(gearbox side) CV Joint Ø [mm]	85
(gearbox side) shoulder Ø [mm]	40

PHOTOS




DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

NISSAN		
SUNNY (86-91) (N13) - 1.3	60 ch	07.1986 > 10.1991
SUNNY (86-91) (N13) - 1.4 LX	75 ch	10.1988 > 08.1991
SUNNY (86-91) (N13) - 1.6	84 ch	06.1986 > 10.1988
SUNNY (86-91) (N13) - 1.6 i	73 ch	06.1986 > 10.1990
SUNNY (86-91) (N13) - 1.6 i 12V	90 ch	10.1988 > 06.1991
SUNNY (86-91) (N13) - 1.7 D	54 ch	06.1986 > 03.1987
SUNNY (86-91) Break (B12) - 1.6	84 ch	06.1986 > 10.1988
SUNNY (86-91) Break (B12) - 1.6 i	73 ch	08.1986 > 05.1989
SUNNY (86-91) Break (B12) - 1.6 i 12V	90 ch	10.1988 > 06.1991
SUNNY (86-91) Break (B12) - 1.7 D	54 ch	01.1986 > 03.1987
SUNNY (86-91) Coupe (B12) - 1.6	84 ch	06.1986 > 10.1988
SUNNY (86-91) Coupe (B12) - 1.6 i	73 ch	06.1986 > 05.1989
SUNNY (86-91) Coupe (B12) - 1.6 i 12V	90 ch	10.1988 > 06.1991
SUNNY (86-91) Hatchback (N13) - 1.3	60 ch	06.1986 > 10.1988
SUNNY (86-91) Hatchback (N13) - 1.4 LX	75 ch	01.1989 > 08.1991
SUNNY (86-91) Hatchback (N13) - 1.6	84 ch	06.1986 > 10.1988

NISSAN		
SUNNY (86-91) Hatchback (N13) - 1.6 i	73 ch	06.1986 > 10.1990
SUNNY (86-91) Hatchback (N13) - 1.6 i 12V	90 ch	06.1986 > 10.1990
SUNNY (86-91) Hatchback (N13) - 1.7 D	54 ch	06.1986 > 03.1987

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.