

DONNEES TECHNIQUES

Length [mm]	910
Number of splines (wheels side)	25
	for vehicles without ABS
(wheels side) shoulder Ø [mm]	55
(wheels side) CV Joint Ø [mm]	90
Number of splines (gearbox side)	24

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

NISSAN		
100 NX (B13) - 1.6	90 ch	03.1990 > 10.1994
100 NX (B13) - 1.6 SR	102 ch	09.1993 > 10.1994

⚠ Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.