

## DONNEES TECHNIQUES

Length [mm]	<b>490</b>
Number of splines (wheels side)	<b>26</b>
<b>for vehicles without ABS</b>	
(wheels side) shoulder Ø [mm]	<b>48</b>
(wheels side) CV Joint Ø [mm]	<b>76</b>
(gearbox side) CV Joint Ø [mm]	<b>75</b>
Number of mounting bores	<b>3</b>
Ø mounting holes [mm]	<b>10</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>SUZUKI</b>		
VITARA (ET, TA) - 1.6 (ET)	82 ch	07.1988 > 12.1991
VITARA (ET, TA) - 1.6 (TA)	80 ch	07.1988 > 01.1995
VITARA (ET, TA) - 1.6 16V (ET)	97 ch	07.1990 > 12.1994
VITARA (ET, TA) - 1.9 D (ET)	68 ch	01.1995 > 03.1998
	75 ch	08.1996 > 03.1998
VITARA Cabrio (ET, TA) - 1.6 (TA)	80 ch	07.1988 > 01.1995
VITARA Cabrio (ET, TA) - 1.6 16V (ET)	97 ch	07.1990 > 03.1999
VITARA Cabrio (ET, TA) - 1.9 D (ET)	68 ch	01.1995 > 03.1998
	75 ch	08.1996 > 03.1999

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.