

## DONNEES TECHNIQUES

Compressed length [mm]	<b>924</b>
Number of splines (wheels side)	<b>26</b>
	<b>for vehicles without ABS</b>
(wheels side) shoulder Ø [mm]	<b>56</b>
(wheels side) CV Joint Ø [mm]	<b>82</b>
Number of splines (gearbox side)	<b>23</b>
(gearbox side) CV Joint Ø [mm]	<b>85</b>

## PHOTOS



## DOCUMENTS

<b>BT-100</b>	<b>Conseils de montage des cardans</b>
<b>BT-104</b>	<b>Soufflets et Triaxes FIAT</b>
<b>BT-105</b>	<b>Soufflets et Triaxes SEAT</b>
<b>BT-131</b>	<b>Refus des carcasses transmissions</b>

## APPLICATIONS

<b>TOYOTA</b>		
CARINA E (92-97) 3/5 portes (_T19_) - 1.6 (AT190)	99 ch	12.1993 > 09.1997
	116 ch	12.1993 > 09.1997
CARINA E (92-97) 3/5 portes (_T19_) - 1.6 16V	106 ch	10.1995 > 09.1997
CARINA E (92-97) 3/5 portes (_T19_) - 1.6 GLI (AT190)	107 ch	04.1992 > 09.1997
CARINA E (92-97) 3/5 portes (_T19_) - 1.8 (AT191)	107 ch	01.1995 > 09.1997
CARINA E (92-97) 3 volumes (_T19_) - 1.6 (AT190)	99 ch	01.1995 > 09.1997
	106 ch	10.1995 > 09.1997
	107 ch	01.1993 > 09.1997
CARINA E (92-97) 3 volumes (_T19_) - 1.6 16V (AT190_)	116 ch	12.1994 > 09.1997
CARINA E (92-97) 3 volumes (_T19_) - 1.6 GLI (AT190)	107 ch	04.1992 > 09.1997
CARINA E (92-97) 3 volumes (_T19_) - 1.8 i 16V (AT191)	107 ch	01.1995 > 09.1997
CARINA E (92-97) Sportswagon (_T19_) - 1.6 GLI (AT190_)	107 ch	01.1993 > 09.1997
CARINA E (92-97) Sportswagon (_T19_) - 1.6 i (AT190_)	99 ch	02.1995 > 09.1997
CARINA E (92-97) Sportswagon (_T19_) - 1.8 i (AT191_)	107 ch	02.1995 > 09.1997