

DONNEES TECHNIQUES

Compressed length [mm]	610
Number of splines (wheels side)	26
	for vehicles without ABS
(wheels side) shoulder Ø [mm]	56
(wheels side) CV Joint Ø [mm]	82
Number of splines (gearbox side)	23
(gearbox side) CV Joint Ø [mm]	85

PHOTOS



DOCUMENTS

BT-100	Conseils de montage des cardans
BT-104	Soufflets et Triaxes FIAT
BT-105	Soufflets et Triaxes SEAT
BT-131	Refus des carcasses transmissions

APPLICATIONS

TOYOTA		
CARINA E (92-97) 3/5 portes (_T19_) - 1.6 (AT190)	99 ch	12.1993 > 09.1997
	116 ch	12.1993 > 09.1997
CARINA E (92-97) 3/5 portes (_T19_) - 1.6 16V	106 ch	10.1995 > 09.1997
CARINA E (92-97) 3/5 portes (_T19_) - 1.6 GLI (AT190)	107 ch	04.1992 > 09.1997
CARINA E (92-97) 3/5 portes (_T19_) - 1.8 (AT191)	107 ch	01.1995 > 09.1997
CARINA E (92-97) 3 volumes (_T19_) - 1.6 (AT190)	99 ch	01.1995 > 09.1997
	106 ch	10.1995 > 09.1997
	107 ch	01.1993 > 09.1997
CARINA E (92-97) 3 volumes (_T19_) - 1.6 16V (AT190_)	116 ch	12.1994 > 09.1997
CARINA E (92-97) 3 volumes (_T19_) - 1.6 GLI (AT190)	107 ch	04.1992 > 09.1997
CARINA E (92-97) 3 volumes (_T19_) - 1.8 i 16V (AT191)	107 ch	01.1995 > 09.1997
CARINA E (92-97) Sportswagon (_T19_) - 1.6 GLI (AT190_)	107 ch	01.1993 > 09.1997
CARINA E (92-97) Sportswagon (_T19_) - 1.6 i (AT190_)	99 ch	02.1995 > 09.1997
CARINA E (92-97) Sportswagon (_T19_) - 1.8 i (AT191_)	107 ch	02.1995 > 09.1997