

## DONNEES TECHNIQUES

|                                  |                                 |
|----------------------------------|---------------------------------|
| Length [mm]                      | <b>915</b>                      |
| Number of splines (wheels side)  | <b>26</b>                       |
|                                  | <b>for vehicles without ABS</b> |
| (wheels side) shoulder Ø [mm]    | <b>56</b>                       |
| (wheels side) CV Joint Ø [mm]    | <b>85</b>                       |
| Number of splines (gearbox side) | <b>20</b>                       |
| (gearbox side) CV Joint Ø [mm]   | <b>85</b>                       |

## PHOTOS



## DOCUMENTS

|               |  |
|---------------|--|
| <b>BT-100</b> | <b>Conseils de montage des cardans</b>   |
| <b>BT-104</b> | <b>Soufflets et Triaxes FIAT</b>         |
| <b>BT-105</b> | <b>Soufflets et Triaxes SEAT</b>         |
| <b>BT-131</b> | <b>Refus des carcasses transmissions</b> |

## APPLICATIONS

| <b>TOYOTA</b>   |        |                   |
|---|--------|-------------------|
| CARINA E (92-97) 3/5 portes (_T19_) - 2.0 GLI (ST191)   | 133 ch | 04.1992 > 09.1997 |
| CARINA E (92-97) 3/5 portes (_T19_) - 2.0 i (ST191)     | 126 ch | 12.1993 > 09.1997 |
| CARINA E (92-97) 3 volumes (_T19_) - 2.0 (ST191)        | 133 ch | 01.1993 > 09.1997 |
| CARINA E (92-97) 3 volumes (_T19_) - 2.0 GLI (ST191)    | 133 ch | 04.1992 > 09.1997 |
| CARINA E (92-97) 3 volumes (_T19_) - 2.0 i (ST191)      | 126 ch | 12.1992 > 09.1997 |
| CARINA E (92-97) Sportswagon (_T19_) - 2.0 GLI (ST191_) | 133 ch | 01.1993 > 09.1997 |
| CARINA E (92-97) Sportswagon (_T19_) - 2.0 i (ST191_)   | 126 ch | 05.1995 > 09.1997 |

**⚠** Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.