


## DONNEES TECHNIQUES

Vehicle Main Current	<b>for vehicles with 12V main current</b>
Rated Power [kW]	<b>2.2</b>
Number of Teeth	<b>9T</b>
Rotation Direction	<b>Clockwise rotation</b>
G/R Reducer	<b>With integrated G/R reducer</b>
Number of Thread Bores	<b>1</b>
Number of mounting bores	<b>3</b>
Plug Type ID	<b>SOL65</b>

## PHOTOS




## DOCUMENTS

**BT-130 Refus des carcasses alternateurs/demarrageurs**

## APPLICATIONS

<b>IVECO</b>		
DAILY (78-00) - 2.4 30-8	72 ch	01.1978 > 12.1989
	72 ch	01.1978 > 12.1989
DAILY (78-00) - 2.5 30-8	82 ch	01.1996 > 08.1998
	82 ch	01.1996 > 08.1998
DAILY (78-00) - 2.8 30-8	84 ch	09.1998 > 05.1999
	84 ch	09.1998 >
	84 ch	09.1998 > 05.1999
DAILY (78-00) - 2.8 30-8 V	84 ch	09.1998 >
DAILY (78-00) - 2.8 30-10	103 ch	01.1997 >
	103 ch	01.1998 > 05.1999
DAILY (78-00) - 2.8 30-10 C	103 ch	01.1997 >
	103 ch	01.1998 >
DAILY (78-00) - 2.4 35-8	72 ch	01.1978 > 12.1989
DAILY (78-00) - 2.8 35-8	84 ch	09.1998 >
	84 ch	09.1998 > 05.1999
DAILY (78-00) - 2.8 35-8 K	84 ch	09.1998 >
DAILY (78-00) - 2.8 35-10	103 ch	01.1996 > 05.1999
	103 ch	01.1996 >
DAILY (78-00) - 2.8 35-10 K	103 ch	01.1997 >

<b>IVECO</b>		
DAILY (78-00) - 2.8 35-12	122 ch	05.1996 > 05.1999
DAILY (78-00) - 2.8 35-12 K	122 ch	09.1996 > 08.1998
DAILY (78-00) - 2.4 40-8	72 ch	01.1983 > 06.1989
DAILY (78-00) - 2.4 40-8 V	72 ch	01.1983 > 06.1989
DAILY (78-00) - 2.8 40-10	103 ch	01.1997 >
DAILY (78-00) - 2.8 40-10 W	103 ch	01.1997 > 05.1999
DAILY (78-00) - 2.8 49-10	103 ch	05.1996 > 05.1999
DAILY (78-00) - 2.8 49-10 K	103 ch	05.1996 >
DAILY (78-00) - 2.8 49-12	122 ch	05.1996 > 05.1999
DAILY (78-00) - 2.8 49-12 K	122 ch	05.1996 >
DAILY (78-00) - 2.8 49-12 V	122 ch	05.1996 >
DAILY (78-00) - 2.8 59-12	122 ch	05.1996 > 05.1999
DAILY (78-00) - 2.8 59-12 K	122 ch	05.1996 >
DAILY (78-00) - 2.8 59-12 V	122 ch	05.1996 >
DAILY (78-00) BUS - 2.8 A 40-10	103 ch	09.1996 >
DAILY (78-00) BUS - 2.8 A 40-12	122 ch	05.1996 >
DAILY (78-00) BUS - 2.8 A 45-10	103 ch	05.1996 >
DAILY (78-00) BUS - 2.8 A 45-12	122 ch	05.1996 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.